



# INH Quality Management

The Needle Dispensing Trolley – Smart Version

# GROZ-BECKERT

## Groz-Beckert KG

Parkweg 2, 72458 Albstadt, Germany

Phone +49 7431 10-0, Fax +49 7431 10-2777

contact-inh@groz-beckert.com

www.groz-beckert.com

In contrast to basic INH, Smart INH offers the option of photographing broken needle pieces and storing them digitally together with the relevant data instead of storing them physically.



## Worktop with tablet device

The smart version of the needle dispensing trolley is equipped with a special worktop. This provides space for a tablet device, which is used for the digital documentation of needle breakages. Any basic version of the needle dispensing trolley can be upgraded to the smart trolley by means of a conversion kit including the smart worktop.



On the smart version, the worktop also has two insertion slots. This means that the needles can be collected in two separate containers. The separate slots can be used individually – for example, separated by day and night shift, or broken and non-broken needles.



## The equipment on the smart needle dispensing trolley



The worktop has a rack that fits any conventional tablet device. The base is designed so that the tablet device can remain securely in the cut-out while charging. In addition, an additional battery (powerbar) can be stored in the base, which guarantees a power supply even if no main power is available for an extended period.



In addition to the rack for the tablet device, there is also a smaller rack for storing the INH identification cards required for using the app INH@site. This ensures that the identification cards are always in the optimal position for being scanned by the camera. Existing company IDs can also be used in place of the INH identification cards.



The needle return box is also stored in this smaller rack for photographing damaged or broken needles. This ensures that these needles are also recorded sufficiently. An LED unit provides additional lighting and guarantees optimal images.

Information on the additional features of the needle dispensing trolley and on the software components INH@site and INH@office is available in the relevant data sheets or in the application brochures:



More information is available in the data sheet  
"Needle Dispensing Trolley Basic Version"



More information is available in the brochure  
"INH Quality Management"